

JACE® 8000

Frequently Asked Questions

FEATURES

Q: Did the default memory allocation change in Niagara 4.11?

A: Yes, the use of RAM Disk is no longer required to maintain the life expectancy of the flash storage. Freeing up the space and its reallocation will improve performance and stability.

Q: Which connections are standard on the JACE 8000?

A: JACE 8000 is available with the following connections: 24VAC/DC Power Supply, (2) isolated RS-485, Wi-Fi, 1 type A USB (Backup & Restore), 1 micro USB (Serial Shell), and (2)10/100 Ethernet Ports.

Q: By upgrading to the JACE 8000, can we move away from JAVA?

A: While Niagara 4 still utilizes JAVA technology, you no longer have to use JAVA as a Web visualization technology. Niagara 4 offers users the opportunity to choose open technologies such as HTML 5 when building/viewing information over the Web.

Q: Are any drivers included with the JACE 8000?

A: Yes. Please refer to list of Niagara 4 drivers, posted online in the [Vykon.com Library](#) or [niagara-community.com](#). Additional Tridium or third-party drivers can also be added.

Q: Does the JACE 8000 have RS 232?

A: RS 232 is available through an expansion module. The base JACE 8000 does not have an RS-232 connection. If accessing serial shell, that can now be done through the micro-USB port on the JACE 8000.

Q: Does every JACE 8000 have Wi-Fi capability?

A: JACE 8000, SKU JACE-8000-CSE-002, is available with Wi-Fi capability, for which 802.11a,b,g, and n networks are supported. Alternatively, JACE 8000, SKU JACE-8000-CSE-003, is also available and does not include Wi-Fi.

Q: Is there an antenna option to get the wireless signals outside of a metal enclosure?

A: The antenna uses a standard SMA connector. An extension can be used to route the antenna and install outside of the enclosure.

Q: Can the JACE 8000 be configured to automatically save the history trending data to the Supervisor computer?

A: Yes.

Q: Will existing NDIO modules work with the JACE 8000, such as with some sort of adapter cable?

A: No. However, Niagara 4.1 has a tool to help convert NDIO points to an NRIO network. NRIO is compatible with the JACE 8000.

Q: What Agency certifications does the JACE 8000 meet?

A: The JACE 8000 meets UL, CE, FCC, and numerous other standards. Please see the data sheet posted online in the [Vykon.com Library](#) for a complete list of certifications.

Q: What is the default IP address for all JACE 8000 units?

A: 192.168.1.140

Q: Will a JACE 8000 route IP data between Ethernet ports?

A: No.

SD CARD

Q: What is the onboard JACE 8000 storage capacity of the SD card?

A: Each JACE 8000 comes with a 4GB microSD card. User space is set at 2GB.

Q: Are you able to upgrade to a larger SD card for more space?

A: JACE 8000 microSD cards will need to be purchased through VYKON. This ensures that the JACE 8000 performs as expected and has long life. VYKON reserves the right to change the card capacity in the future.

JACE[®] 8000 Frequently Asked Questions

Q: What happens if the microSD needs to be replaced?

A: VYKON recommends that you utilize a Supervisor or new JACE 8000 USB Back-Up & Restore to back up your JACE periodically. Similar to a Niagara AX JACE today, licenses can be transferred over to new hosts and a backup dist can be loaded. Contact your distributor for replacement SD cards.

Q: Will our suppliers be able to carry SD cards instock?

A: Yes. Please check with your Niagara representative for additional details.

Q: Can an SD card Host ID be generated on an engineering laptop and then transferred to the JACE 8000?

A: No.

Q: Can the license, station and drivers be transferred from one JACE 8000 to another via the microSD card?

A: Yes. The JACE 8000 will need the system password from the old JACE 8000.

VOLTAGE

Q: What input power does the JACE 8000 need?

A: The JACE 8000 accepts 24VAC/DC without additional modules. VYKON offers a standard line voltage adapter (WPM-8000) for the JACE 8000.

USB

Q: Can I use a USB flash drive with my JACE 8000?

A: Yes. After inserting a USB flash drive, you can do a complete station backup or restore. See JACE 8000 documentation for additional details.

Q: Using the USB flash connection, would we be able to export history to an external drive in real time?

A: The USB connector is defined for temporary use and not meant to support permanently installed storage.

LICENSING

Q: How is the JACE 8000 licensed?

A: All JACE 8000s come licensed by devices and points. After determining how many devices will be integrated into the JACE 8000, select the license with the appropriate amount of capacity. For example, if you are integrating 20 BACnet, 10 LON and 10 Modbus devices, the NC-8050 device core could be selected to support up to 50 devices.

Q: How will using the JACE 8000 in Niagara AX be licensed — by Devices or Resources?

A: The JACE 8000 will initially be available with Niagara 4.1. We are looking to release a 3.8U build in the future that will offer JACE 8000 support. Similar to Niagara 4, the JACE 8000 will be licensed by devices and points.

Q: With the Device/Point licensing, are they both hard limits? For example, 8010 can support 10 devices or 500 points. Is there flexibility to exceed one of those limits?

For example, 12 devices with 10 points each?

A: The JACE 8000's device/point license applies to which limit you reach first. In the example above, 12 devices exceed the 10-device limit, even though only 120 points were used. The device/point license are hard limits, however upgrade packs will be available to upgrade the license.

Q: Will my JACE 3E, 6, 6E or 7 have device/point limits if upgraded to Niagara 4?

A: No

Q: On licensing, will it still be possible to upgrade an existing license to a license with more capacity? For example, if a project is expanded during construction.

A: Yes, upgrade device/point packs are available. See your distributor for details.

Q: Will the points being used by the JACE 8000 be viewable?

A: Yes. Station summaries can be viewed from the resource manager.

Q: What are the device and point packs being offered?

A: The JACE 8000 is available with 5, 10, 25, 100 and 200 device base licenses. Additional device/point upgrades can be added to any base license. They are available in 10, 25 and 50 device upgrade packs.

JACE[®] 8000 Frequently Asked Questions

UPGRADE PACKS

Q: Is there a limit to how many Device upgrade packs I can add to a JACE 8000?

A: While there isn't a hard limit on the number of upgrade packs that can be added, users should monitor CPU utilization, heap usage and integration bus limits when adding device upgrades.

Q: If we have an 8200, and we have 200 controllers connected, can we add one additional controller without another JACE? Or are we absolutely locked to controller number?

A: Upgrade packs are available to enable more than 200 devices.

MAINTENANCE

Q: When does software maintenance start on the JACE 8000?

A: Software maintenance starts when the JACE software license is purchased. Please see your distributor for details.

Q: Is Maintenance and Warranty the same thing?

A: No. Software maintenance enables access to the latest Niagara build with new features and software updates. Warranty covers the JACE 8000 from manufacturing defects.

Q: Does the JACE 8000 automatically include maintenance at the time of purchase?

A: Yes, it includes 18 months from the date of the creation of the license, when bundled with the INIT license part. Initial maintenance is a separate line item that must be chosen while purchasing.

Q: Can I buy more than 1-year maintenance at a time?

A: Yes. SMA can be purchased for 1-, 3- or 5-year periods.

Q: How will multiple quantities of maintenance appear on a license?

A: Dates will run consecutively (i.e., buy qty 2 = 2 yrs.). Date will show in license header details and in license view.

Q: What if I choose not to renew my Niagara 4 maintenance?

A: If the SMA has expired on the JACE, it will continue to run the station. However, the JACE will not have access to any new versions, update builds or patches for Niagara 4. Gap charges will apply if you choose to renew once the SMA has expired.

MIGRATION

Q: How do I take my JACE 3, JACE 6 and JACE 7 up to Niagara 4? How do you buy it when you're rolling out a new software maintenance policy?

A: Upgrading these models to run Niagara 4 is no longer available.

Q: Would you be able to revert back to Niagara AX from Niagara 4 if you wanted to?

A: The conversion disk file will clean it and convert back to the Niagara AX system. Niagara Central will host both Niagara AX and Niagara 4 licenses.

Q: When migrating from Niagara AX to Niagara 4, should you start by upgrading the existing JACE hardware first?

A: No, you should upgrade the Niagara Supervisor to Niagara 4 first.

Q: Which JACEs can be updated to Niagara 4?

A: The JACE 3E, JACE 6, JACE 6E and JACE 7 can no longer be upgraded to run Niagara 4. The JACE 8000 is available to run Niagara 4.

Q: Can I have a mixed Niagara AX / Niagara 4 job?

A: Yes, however the Supervisor needs to be at highest version.

JACE[®] 8000 Frequently Asked Questions

OPTION MODULES

Q: How many accessory cards, or expansion modules, can we add?

A: Up to 4 in various combinations. See the data sheet posted online in the [Vykon.com Library](#) for additional details.

Q: Will we have the ability to place the modular expansion cards on a bus? Or do they have to "snap" together?

A: Option modules will need to be directly connected to the JACE 8000.

Q: Which option card modules will be available at launch?

A: The NPB-8000-2X-485, NPB-8000-LON and NPB-8000-232 are now available.

Q: How many LON Option Module cards can be attached to the JACE 8000?

A: Up to 4 can be attached.

ORDERING

Q: Can I order a JACE 8000 to run Niagara AX 3.8?

A: No. You can no longer purchase the feature required to downgrade a JACE 8000 to Niagara AX.

Q: If I don't use all the devices I purchased, can I transfer the device to another license?

A: No. Unless ordering a replacement unit, unused license elements cannot be transferred.

Q: Can I still order Legacy JACEs?

A: No. These are no longer available for purchase. All new orders should purchase a JACE 8000.

Q: How do I buy drivers for JACE 8000?

A: Open drivers are now included, and a list of Niagara drivers is posted online at tridium.com/us/en/Products/niagara-drivers. Any additional boutique drivers will be purchased ad hoc as before, though global capacity limits apply to all drivers used on the JACE 8000.

Q: How can I buy the JACE 8000?

A: VYKON offers multiple options for purchasing JACE 8000s. Hardware and software can be bundled together or separately. Also, you can add capacity later, as needed. Please contact your distributor for details.

WARRANTY

Q: When does the warranty start on the JACE 8000?

A: The hardware warranty starts when purchased from VYKON. For North America, the warranty covers 18 months.

Q: If the hardware fails, what is the warranty process?

A: Please contact your distributor for details.